


nÂ°	Artikel	Aantal gebruikt
1	321132 BLADE HOLDER (A)	1
2	322709 NUT M4 (BLACK)	1
3	324472 PLUNGER	1
4	996401 PACKING WASHER	1
5	996400 FELT PACKING	1
6	996407 O-RING (1AP-12)	1
7	956589 METAL	2
8	324471 UPPER COVER	1
9	305583 HEX. HOLE BOLT M5X20 (NEW 6695491)	2
10	305574 HEX.SOCKET HD.BOLT M5X16	2
11	322134 SPECIAL BOLT M4	1
12	321130 CAP	1
13	321131 LEVER (A)	1
14	321135 SPRING (D)	1
15	321134 HOLDER PIN (B)	1
16	318483 SPRING (B)	1
17	319866 BASE	1
18	951039 MACHINE SCREW (W/SP.WASHER) M4X12	5
19	324474 COVER PLATE	1
20	324473 FRONT COVER	1
21	993244 SEAL LOCK FLAT HD. SCREW M4X12	3
22	319849 BEARING COVER (B)	1
23	6901VV BALL BEARING 6901VVCMP52L	1
24	319848 SPINDLE	1
25	954789 METAL (B)	1
26	326353 CAP (A)	1
27	996399 HEX.SOCKET HD.BOLT M5X12 (W/FLANGE)	1
28	986011 TAPPING SCREW D5X30 (W/SP.WASHER)	4
29	319844 GEAR COVER ASS'Y	1
30	319875 SEALLOCK HEX.SOCKET HD BOLT M5X12	2
31	319851 NYLOCK HEX. SOCKET HD BOLT M6X16	1
32	319856 SEAL PACKING	1
33	319874 PACKING (B)	1
34	983567 CONNECTOR HOLDER	1
35	996405 CONNECTOR (OLD 983568)	1
36	983541 CONNECTING PIECE (A) (OLD 983566)	1
37	324470 NEEDLE ROLLER H-7108 (OLD 983560)	1
38	319852 BALANCE WEIGHT	1

nÂ°	Artikel	Aantal gebruikt
39	324469 GEAR	1
40	670514 RETAINING RING (E-TYPE)	1
41	6001VV BALL BEARING 6001VV	1
42	319843 BEARING COVER (A)	1
43	360855 ARMATURE ASS'Y DC 14.4 VOLT	1
44	608VVM BALL BEARING 608VVC2PS2L	1
45	324468 MAGNET	1
46A	334888 BRUSH BLOCK SET	1
46	324478 BRUSH BLOCK	1
47	318247 FERRITE CORE	1
48A	330155 HOUSING SET (A+B)	1
49	319847 BRUSH CAP	2
50	999068 CARBON BRUSH (1 PAIR) (OLD 999058)	2
51	886342 HITACHI PLATE	1
52	319861 DC-SPEED CONTROL SWITCH	1
53	319760 PUSHING BUTTON	1
54	993963 MACHINE SCREW M3X12 (W/WASHERS)	1
55	319812 HEAT SINK	1
56	330156 CONTROLLER TERMINAL SET	1
57	NAME PLATE	1
58	301653 TAPPING SCREW (W/FLANGE) D4X20 (BLACK)	9
59	329901 BATTERY BSL 1430 (USA,CAN)	2
60	328709 PACKING	1
61	322708 SPECIAL BOLT M4 SET	1
501	944458 HEX. BAR WRENCH 4MM	1
502	318621 SABER SAW BLADES NO.132 203L (5 PCS.)	1
503	318613 SABER SAW BLADES NO.103 150L P.14 (5 PCS)	1
504	329897 BATTERY COVER	1
505	CHARGER (MODEL UC 18YRSL)	1
506	330157 CASE	1
602	958182 SABER SAW BLADES NO.2 (5 PCS.)	1
603	958183 SABER SAW BLADES N.3 (NEW 750057)	1
604	959611 SABER SAW BLADES NO.4 (5 PCS.)	1
605	958185 SABER SAW BLADES NO.5 (5 PCS.)	1
606	958188 SABER SAW BLADES NO.8 (5 PCS.)	1
607	996427 SABER SAW BLADES NO.9 (3 PCS.)	1
608	318611 SABER SAW BLADES NO.101 150L P.10 (5 PCS)	1
609	318612 SABER SAW BLADES NO.102 228L P.10 (5 PCS)	1

nÂ°	Artikel	Aantal gebruikt
610	318614 SABER SAW BLADES NO.104 228L P.14 (5 PCS	1
611	318617 SABER SAW BLADES NO.107 150L P.24 (5 PCS	1
612	318618 SABER SAW BLADES NO.108 228L P.24 (5 PCS	1
613	324818 SABER SAW BLADES NO.109 150L P.18 (5 PCS	1
614	324819 SABER SAW BLADES NO.110 228L P.18 (5 PCS	1
615	318619 SABER SAW BLADES NO.121 305L P.6 (5 PCS.	1
616	318620 SABER SAW BLADES NO.131 305L P.10/14(5PC	1



Rev.4

形 名
CR14DSL