

Bestelnummer: DH1826DAW2Z



## DH1826DAW2Z

**Accu boor-breekhamer - 18 V / 3,2 J -Exclusief lader en accu's - HSC II koffer**

3 standen: boorhamer, boren en breken | Reactive Force Control (RFC) stopt de motor wanneer de boor plotseling klem zit | Boor/beitel verwisselen in 1 stap | constante snelheid | Auto stop; instelbare diepteregeling | exclusief accu's en lader in HSC II